

Here's the fitment data (BJ= ball joint; TRE= tie rod end):

AVAILABLE BOOTS & SEALS

Part Number	ID— Large End	ID— Small End	Height (free)	Application
OEM Mopar Seals				
52006405	1.91"	0.78	1.75	BJ
2835896	1.08	0.62	0.933	TRE
3897412	1.30	0.69	1.00	TRE
52006404	1.93	0.88	1.60	BJ
2835895	1.35	0.62	0.55	TRE
Dorman-Help! Boots				
133567*	1.75	0.75	1.75	BJ
133567*	1.30	0.63	1.00	TRE
Energy Suspension boots**				
9.13103	1.22	0.45	0.95	TRE
9.13101	1.35	0.55	1.00	TRE
9.13105	1.45	0.50	0.95	TRE
9.13119	1.60	0.65	1.00	BJ
9.13131	1.60	0.62	1.15	BJ
*—2-pack; this P/N brings one of each size listed				
**— Heavy wall polyurethane. Great, but keep away from heat sources.				