



prestolite®

SERVICE

INFORMATION

Vacuum Advance Data

Distributor

Page 1 of 4

Issued 3/16/78

DISTRIBUTOR VACUUM ADVANCE DATA

All test figures shown in the tabulation are given in distributor degrees and inches of mercury. Allowable variation is ± 1 inch of vacuum at all points except the full advance, at which point the tolerance is $\pm 1^\circ$ advance.

Vacuum Curve No.	Start or Zero Adv. In. of Mercury	Intermediate Advance						Full Advance	
		Adv.°	In. of Mercury	Adv.°	In. of Mercury	Adv.°	In. of Mercury	Adv.°	In. of Mercury
452	5	2	6-3/4	4	8-1/2	6	10-1/4	8	12
453	5-1/4	2	7-5/8	4	10	6	12-1/2	8	15
454	5-1/8	1	6-1/4	3	8-5/8	5	10-7/8	6	12
455	5	2	7-1/4	4	9-1/2	6	11-3/4	8	14
456	5	2	6-3/4	5	9-1/2	8	12-1/4	10	14
464	4	2	5-5/8	5	8	8	10-3/4	10	12
467	3-1/2	2	5-3/4	5	9-1/4	8	12-3/4	10	15
472	5-1/4	1	7	2	8-3/4	3	10-1/2	5	14
491	4-7/8	2	6-1/8	4	7-1/2	6	8-3/4	8	10
501	6	2	9	4	11-7/8	6	14-7/8	7.5	17
505	3	2	5	3	6	5	10	6	12
517	5	2	8	4	11	6	13-7/8	7.5	16
524	4-3/4	2	6-1/4	5	8-3/8	8	10-1/2	10	12
527	5-1/8	1	6-5/8	3	9-5/8	5	12-1/2	6	14
532	5	1	6	3	8	5	10	7	12
550	7	1	8-5/8	3	12	4	13-1/2	5	5 16
583	10	1	11-1/8	3	13-1/2	5	15-7/8	6	17
584	5	2	7-3/4	4	10-1/2	6	13-1/4	8	16
593	4	1	5-5/8	2	7-1/4	3	8-3/8	5	12
613	6	1	7	3	9-1/4	4	10-3/8	5.5	12
614	5	1	6-1/2	3	9-1/4	5	12-1/8	7	15
619	5	2	7-1/4	5	10-1/2	8	13-3/4	11	17
620	5	2	7-3/8	5	11	8	14-5/8	10	17
621	5	2	8	4	11	6	14	8	17
622	5	1	7	3	11	5	15	6	17
626	3-5/8	2	6-7/8	4	10-1/8	6	13-1/2	7	15
633	4	2	5-1/2	5	7-3/4	7	11-1/4	9	14-3/4
641	4	1	6-3/8	2	8-3/4	3	11-1/4	5	16
655	2	1	4	3	8	5	12	6	14
661	6-7/8	2	8	4	9-1/4	6	10-3/8	7.5	11-1/4
740	8-1/2	2	10-1/4	4	12	6	13-3/4	7.5	15
745	5	2	6-7/8	4.5	9	6	12	7.5	15
749	4	2	5-1/2	4	7	5	7-7/8	6.5	9
767	5	2	7-5/8	4	10-1/8	6	12-3/4	8.5	16
768	5	2	7	4	9	6	11	9	14
773	5	1	6-5/8	3	10	5	13-3/8	6	15

File in the
L-600 SERVICE MANUAL



Vacuum Advance Data
Distributor