

CODE	PART NAME AND DESCRIPTION	PER CAR	CU. IN. DISPLACEMENT & PISTON BORE SIZE					
			273	318	340	383	426	440
			3.62	3.91	4.04	4.25	4.26	4.32

EIGHT CYLINDER ENGINES

9-64-0 ENGINE FRONT SUPPORT Cont'd.

9-64-24	BRACKET Cont'd.							
	Left, except B2, L2	1	—	—	—	2863 751	—	2863 751
	Left, B2, L2	1	—	—	—	2465 862	—	—
	Right	1	—	—	—	—	2780 672	—
	Left	1	—	—	—	—	2780 673	—
	BOLT, Bracket to Block	AR	9417 818	9417 818	9417 818	9417 818	—	9417 818
	BOLT, Bracket to Block, R2, W2	1	—	—	—	9427 473	—	9427 473
	NUT, Bracket to Cylinder Block Bolt	AR	6026 750	6026 750	6026 750	6026 750	—	6026 750
	WASHER, Bracket to Cylinder							
	Block Bolt, B2, L2	2	—	—	—	6023 050	—	—
9-64-35	CABLE, Engine Roll, w/Auto. Trans., P, D	1	—	2951 589	—	—	—	—
	w/Auto. Trans., P, D, C, Y	1	—	—	—	2951 590	—	2951 590
9-64-36	SPACER, Engine Roll							
	Cable, w/Auto. Trans., P, D	1	—	2951 593	—	—	—	—
	P, D, C, Y	1	—	—	—	2951 592	—	2951 592
9-64-37	BUSHING, Engine Roll Cable, w/Auto. Trans., P, D, C	1	—	2951 594	—	2951 594	—	2951 594
	Y	1	—	—	—	—	—	2951 594

9-67-0 ENGINE FRONT SUPPORT INSULATOR

9-67-4	INSULATOR, Engine Front							
	Support, V2, B2, L2	2	2806 779	2806 779	2806 779	—	—	—
	R2, W2, Sta. Wgn.	2	—	2863 735	—	2863 735	—	—
	R2, W2, except Sta. Wgn.	2	—	2536 121	—	2536 121	—	2536 121
	P2, D2, C, Y	2	—	2536 121	—	2536 121	—	2536 121
	Right, B2, L2	1	—	—	—	2536 121	—	—
	Left, B2, L2	1	—	—	—	2465 861	—	—
	Right	1	—	—	—	—	2532 708	—
	Left	1	—	—	—	—	2468 184	—
	NUT, Insulator to Frame	2	6023 353	6023 353	6023 353	—	—	—
	BOLT, Insulator to Frame	1	—	—	—	—	6026 968	—
	WASHER, Insulator to Frame Bolt	AR	—	6023 050	—	6023 050	6023 050	6023 050
	SCREW, w/WASHER, Support to Frame	1	—	—	—	—	6024 023	—

9-69-0 ENGINE REAR SUPPORT INSULATOR BRACKET

9-69-12	SPACER, Engine Rear Support Insulator Bracket, P, D, C, Y	2	3410 700	3410 700	3410 700	3410 700	—	3410 700
---------	--	---	----------	----------	----------	----------	---	----------

9-71-0 ENGINE REAR SUPPORT INSULATOR

9-71-5	INSULATOR, Engine Rear							
	Support, V, B, L, R, W	1	2533 145	2533 145	2533 145	2533 145	—	2533 145
	P, D, C, Y	1	—	2892 471	—	2892 471	—	2892 471
	R, W	1	—	—	—	—	2660 673	—
	SCREW, V2, B2, L2, R2, W2	2	9417 471	9417 471	9417 471	9417 471	9417 471	9417 471
	SCREW, P2, D2, C, Y	2	—	6024 023	—	6024 023	—	6024 023
	Bolt, Insulator to Crossmember, P, D, C, Y	1	—	6028 237	—	6028 237	—	6028 237
	Nut, Insulator to Crossmember Bolt	1	—	6023 353	—	6023 353	—	6023 353

TYPE LETTERS Indicates

B - Barracuda

V - Valiant
L - DartR - Belvedere
W - CoronetP - Plymouth
D - DodgeC - Chrysler
Y - Imperial

AR Indicates use as required.

Indicates parts not listed in any previous parts book.

Numerals in parentheses () refer to notes.

★ Indicates change or addition.

Printed in U.S.A.
January 1971