


	Dart	Coronet	Charger*
Instrument Cluster Illumination	** 158 (4)	** 158 (4)	** 57 (3) 158 (3)
License Light	67	67	67
Map Light	89	90	90
Oil Pressure Indicator	158	158	Gauge
Park and Turn Signal	1157 A (2)	1157 (2)	1157 A (2)
Radio	** 1816	** 1816	** 1816
Radio with Tape		** 1815	
Reverse 4-Speed Transmission Indicator	53	53	53
Sealed Beam—Hi-Beam (No. 1)		4001	4001
Sealed Beam—Hi-Lo Beam (No. 2)		4002	4002
Sealed Beam—Single "7"	6012		
Tachometer		** 57	*
Tail, Stop and Turn Signal	1157 (2)	1157 (2)	1157 (4)
Trunk and/or Under Hood Light	1004	1004	1004
Turn Signal Indicator (panel)	158 (2)	158 (2)	57 (2)

*Included in Instrument Cluster Lighting.
 ** Headlamp Rheostat Dimming.
 *** Hood Mounted.

WIRING DIAGRAMS

INDEX

	Page		Page
Accessory Lamps Wiring—Dart	112	Front End Lighting—Charger	100
Air Conditioner Wiring	See group 24	Front End Lighting—Coronet	100
Body Wiring Diagram—Charger	98	Front End Lighting—Dart	99
Body Wiring Diagram—Except Station Wagon—Coronet	97	Instrument Panel Accessory Wiring Diagram—Coronet	104-105
Body Wiring Diagram—Station Wagon— Coronet	97	Instrument Panel Wiring Diagram—Coronet ..	106-107
Console Wiring Diagram—Dart	99	Instrument Panel Wiring Diagram—Charger ..	108-109
Electric Window Lift Wiring Diagram— Coronet and Charger	111	Instrument Panel Wiring Diagram—Dart	102-103
Engine Compartment Wiring Diagram—Except Hemi Engines—Coronet—Charger—Dart	101	Rear Window Defogger Wiring Diagram— All Models	96
Engine Compartment Wiring Diagram— Hemi Engines	110	Speed Control Wiring Diagram—Charger and Coronet	111



NR226 A

Fig. 1—Rear Window Defogger Wiring Diagram—All Models